



1 Preparing Substrates

Make sure the substrates such as walls, floors, countertops, backsplashes, etc are smooth and ash-free



2 Prepare Tools

Tools like ceramic adhesive, grout, grout sealer, rubber float, sponge, spacer, spirit level, wet saw should be prepared.



3 Preparing Adhesives

Add appropriate water to the adhesives and stir, until it forms a thick paste.



4 Apply the adhesives to the substrates

Apply a thin, even layer and avoid excess of adhesive. Scrape the adhesive upwards.



5 Apply the Tile Sheet

Apply the tile sheet to the wall, press firmly and evenly onto the adhesive.



6 Preparing the Grout

Add appropriate water to the grout and stir, until it forms a thick paste.



7 Apply the Grout to the Tile Sheet Surface

Take out the spacer between sheets and ensure the grout applied to the gap.



8 Cleaning

Clean the surface of mosaic with towel or sponge.



9 Curing for 24 hours before Use

With minimum cure time for 24 hours after installation, the wall can be used.